

## ASSEMBLY INSTRUCTIONS



The FlexiBox is supplied as a completely knocked down kit packed in a card board carton.



Each box contains the following parts.

1. Top and Bottom Cover
2. Side Covers
3. Front Door with lock
4. 19" mounting angle - 1 pair
5. Hardware set for assembly.



### Step 1

Place the Bottom Cover on a work table ( Bottom Covers are provided with cut-outs for Cable entry).

Stand one of the Side Covers inside the Bottom Cover as shown in the photo. Then attach them to each other as shown using the M6 screws and nuts provided.



### Step 2

Repeat Step 1 to install the other Side Cover



### Step 3

Now Place the Top cover over the side covers. (Top cover by default will be supplied with 2 fan cutouts and Fan Grills).

Note : Fans have to be ordered separately.



### Step 4

Fix the Top Cover to the side Covers with the M6.0 Screws and Nuts provided.



### Step 5

Note that the 19" angles are to be mounted only at the front of the Flexibox. Fix these 19" mounting angles at the bottom and top with the M6.0 Screws provided.



### Step 6

The Front door is supplied with spring loaded Hinge Pins. Place the bottom hinge pin at the hole provided on the Bottom cover. To engage the pin on the top, pull the pin down and position the door to match the hole provided on the top cover.



The Flexibox is ready for installation.

Use the template provided as a location guide to drill holes in the wall. Use the wall plug and hardware provided.